# **USB** cable User Installation Manual

### For Windows vista

(11/2009)

1. Power on your computer and boot to Windows.


2.Locate the USB port of your computer and plug in the USB cable.

Windows will detect the new device and will initiate the Found New Hardware Wizard prompting you to install the software for the detected USB Device.


#### 3. Click Cancel to continue.



#### 4.right clik computer→select Manage



#### 5. Computer Management → Device Manager → right clik USB – Serial controller → Update Driver Software



#### 6.select Browse my computer for dirver software

v do you want to search for driver software? Search automatically for updated driver software Windows will search your computer and the Internet for the latest driver software	
for your device. Browse my computer for driver software	
Locate and install driver software manually.	

	priver Software - USB-S	on your computer			
	iver software in this loc				
[			•	Browse	
✓ Include s	bfolders				
					- -
This li		t of device drivers on i riversoftware compatible wi y as the device.			
This li	t will show installed dr	riversoftware compatible wi			

## 7.select Let me pick from a list of device drivers on my computer

## 8.click Next to continue

Select your device's type from the list below.	
Common hardware types:	
Show All Devices	<u>.</u>
G1883 Device Class	E
AVC Device Class	
A Batteries	
8 Bluetooth Radios	
Computer	
Disk drives	
Not splay adapters	
BVD/CD-ROM drives	
Floppy disk drives	
Floppy drive controllers	
🕼 Human Interface Devices	-
	· · · · · · · · · · · · · · · · · · ·

## 9.click Have Disk…

Update Driver Software - USB-Serial Controller	
Select the device driver you want to install for th	iis hardware.
Select the manufacturer and model of your hardware device a have a disk that contains the driver you want to install, click h	
Show compatible hardware	
Model	
Prolific USBto-Serial Comm Port	
This driver is not digitally signed!	Have Disk
Tell me why driver signing is important	13

#### **10.click Browse**

install Fro	m Disk	
	Insert the manufacturer's installation disk, and then make sure that the correct drive is selected below.	OK Cancel
	Copy manufacturer's files from:	
	AN	Browse

## 11.click vista

Locate File							X
Look in:	BVD Drive	BVD Drive (E:)			G 💋	€ 🛄 🔁	
Recent Places	Name 98ME_2k	Date modif _XP					
Network	File name: Files of type:	SERSPL.IN	4			•	Open Cancel

## 12 select "serspl"

Locate File							<b>.</b>
Look in:	📗 vista	퉳 vista			- 🧿 🎓 🖽 -		
Pa	Name	Date modif		Size			
2	SERSPL						
lecent Places	SERWPL						
Desktop							
5							
Jacky							
Computer							
Network							
	File name:	SERSPL				-	Open
	Files of type:	Setup Inform					Cancel


## 13.click ok to continue

nstall Fro	om Disk	EX
J.	Insert the manufacturer's installation disk, and then make sure that the correct drive is selected below.	OK Cancel
	Copy manufacturer's files from:	
	E:\vista 👻	Browse

## 14. click Next to continue

🚱 🧕 Update Driver Software - USB-Serial Controller	
Select the device driver you want to install for Select the manufacturer and model of your hardware de have a disk that contains the driver you want to install,	evice and then click Next. If you
Show compatible hardware Model Prolific USBto-Serial Bridge	
This driver is not digitally signed!     Tell me why driver signing is important	Have Disk
	Ntt Cancel


#### 15. installing…




#### 16.select Install this driver software anyway



#### 17. install successfully



## 18. Verifying the Installation



You should see the Prolific USB-to-Serial Comm Port (COM \*) device listing. This also means that Windows has assigned the device to COM \* port.